

طريقة وضع اعدادات راوتر Netgear

نفتح صفحة انترنت و نكتب بالعنوان 192,168,0,1 .
نكتب

username: **admin**

password: **admin or virgin**



The screenshot shows the 'Basic Settings' page in the Netgear router's web interface. The left sidebar contains a navigation menu with categories like 'Setup Wizard', 'Setup', 'Security', 'Maintenance', and 'Advanced'. The main content area is titled 'Basic Settings' and includes the following sections:

- Does Your Internet Connection Require A Login?**: Radio buttons for 'Yes' (selected) and 'No'.
- Encapsulation**: A dropdown menu set to 'PPPoE (PPP over Ethernet)'.
- Login**: A text field containing '82865306@paltem.ps'.
- Password**: A text field containing '82865306'.
- Service Name (If Required)**: A text field containing 'paltem'.
- Idle Timeout (In Minutes)**: A text field containing '0'.
- Internet IP Address**: Radio buttons for 'Get Dynamically From ISP' (selected) and 'Use Static IP Address'. Below is an IP address field.
- Domain Name Server (DNS) Address**: Radio buttons for 'Get Automatically From ISP' (selected) and 'Use These DNS Servers'. Below are fields for 'Primary DNS' and 'Secondary DNS'.
- NAT (Network Address Translation)**: Radio buttons for 'Enable' (selected) and 'Disable'.

At the bottom of the page, there are three buttons: 'Apply' (highlighted in green), 'Cancel', and 'Test'.



The screenshot shows the 'ADSL Settings' page in the Netgear router's web interface. The left sidebar is the same as in the previous screenshot. The main content area is titled 'ADSL Settings' and includes the following sections:

- Multiplexing Method**: A dropdown menu set to 'LLC-BASED'.
- VPI**: A text field containing '8'.
- VCI**: A text field containing '35'.

At the bottom of the page, there are two buttons: 'Apply' (highlighted in green) and 'Cancel'.