


طريقة وضع اعدادات راوتر SpeedTouch

استخدام متصفح انترنت نضع العنوان الآتي :
192.168.1.254




The screenshot shows the PalTem SpeedTouch web interface. The header includes the PalTem logo and the URL www.paltem.ps. The user is logged in as 'admin'. The main content area is divided into several sections:

- SpeedTouch**: Information section showing Product Name: SpeedTouch 530 and Software Release: 5.3.3.4.
- Broadband Connection**: Internet status is 'Connected'. A 'Disconnect' button is visible.
- Toolbox**: Contains links for Remote Assistance (Disabled), Game & Application Sharing, and Firewall (Disabled).
- Home Network**: Shows Ethernet connection details, including the IP address admin-r57140852.



The screenshot shows the PalTem SpeedTouch web interface with the 'SpeedTouch' configuration page selected. The user is logged in as 'admin'. The main content area is divided into several sections:

- SpeedTouch**: Information section showing Product Name: SpeedTouch 530, Serial Number: 05430T90U, and Software Release: 5.3.3.4.
- Configuration**: Shows Service Name: Router (modified by user) and Time Since Power-on: 0 days, 0:02:23.
- Pick a task...**: A list of tasks with arrows pointing to them:
 - [Set Up](#)
 - [Restart](#)
 - [Return to Factory Default Settings](#)
 - [View event logs](#)
 - [Check connectivity to the Internet](#)



Internet Account Settings
Specify the details of your Internet Account. All information should be provided by your ISP.

User Name:
Enter your Internet connection user name.

Password:
Enter your Internet connection password.

Confirm Password:
Re-enter your password.


www.paltm.ps

speedtouch™

Access Control
Specify user name and password to prevent unwanted access to the SpeedTouch management interface.

User Name:
Enter a user name.

Password: هنا نضع كلمة المرور التي نريدها للدخول لصفحة الراوتر
Enter a password.

Confirm Password:
Re-enter the password.


www.paltm.ps

speedtouch™

Start configuration ?
Review settings before configuring the SpeedTouch.

The Wizard has enough information to configure your SpeedTouch™. If you want to review or change settings, click Back. Click Start to start configuration.

Settings:

Routed Internet Connection:
VPI/VCI 8,35
Connection Type PPP over Ethernet (PPPoE)

Internet Account Settings:
User Name :
Password : ••••••••

Access Control:


www.paltm.ps

speedtouch™

